

BB DONGLE FOR BLACKBERRY



User Manual V2.0
Dongle Version V1.1

User Manual and Dongle Software available at:

www.bbdongle.com

First ever powerful dongle to unlock blackberry in a minute

Simply Install the software and connects dongle to the computer and run the reader file. It will give you the blackberry codes.

How to read Blackberry code:

- 1. Power on the phone fully**
- 2. Connect the dongle to computer.**
- 3. Connect the phone to the Computer.**
- 4. Open the blackberry desktop software.**
- 5. Run the reader file.**

That's it.

Code will be displayed on the screen.

Entering unlocks Codes:

- 1. Go to option menu**
- 2. Select 'Sim Card' menu option**
- 3. You will see Sim information screen but no information (Blank)**
- 4. Hold the "shift" key and type "MEPD" on in case of 7100 series "MEPPD" (no writing will appeared on screen).**
- 5. You will now see the screen details sim lock status and you will see active sim lock.**
- 6. To disable this now hold ALT key type "MEP2" or in case 7100 "MEPP2". No writing will appear on screen).**
- 7. New window will appear asking for code.**

8. Enter the code which is read by reader file and press ok with jog dial.
9. Phone will display the message 'Code accepted'. Now your phone is unlocked.

Download Blackberry desktop manager version 4.1 from
<http://www.blackberry.com/support/>

Go to Download /Select “service packs” option

Download desktop version 4.1 on your computer and install the software.

If your firmware/software version for blackberry is 4.0.XXXXXXXXXX no firmware required proceed with unlock. If your firmware for blackberry is 3.0XXXXXXXX then first you must upgrade your blackberry firmware to unlock.

Latest Firmware can be downloaded from the website:

Software Download for Nextel Communications Inc.

<https://www.blackberry.com/Downloads/entry.do?code=C8ED21DB4F678F3B13B9D5EE16489088>.

2. Software Download for Telus Mobility

<https://www.blackberry.com/Downloads/entry.do?code=02A32AD2669E6FE298E607FE7CC0E1A0>

3. Software Download for Bell Mobility Inc.

<https://www.blackberry.com/Downloads/entry.do?code=6C3CF77D52820CD0FE646D38BC2145CA>

4. Software Download for Sprint Spectrum L.P

<https://www.blackberry.com/Downloads/entry.do?code=FC3CF452D3DA8402BEBB765225CE8C0E>

5. Software Download for Rogers Wireless Inc.

<https://www.blackberry.com/Downloads/entry.do?code=1905AEDAB9BF2477EDC068A355BBA31A>

6. Software Download for Cingular

<https://www.blackberry.com/Downloads/entry.do?code=577BCC914F9E55D5E4E4F82F9F00E7D4>

7. Software Download for Orange UK

<https://www.blackberry.com/Downloads/entry.do?code=2E65F2F2FDAF6C699B223C61B1B5AB89>

Steps to upgrade your Blackberry firmware:

- 1. Start your blackberry desktop manager .and plug in your blackberry.**
- 2. Desktop Manager prompts you that there is a new version.**
- 3. Proceed with install.**
- 4. Make a backup before going to upgrade.**
- 5. Once update finish your blackberry will restart automatically.**
- 6. Now you can proceed to unlock your phone.**

Steps to putting codes in blackberry

After getting codes from Reader file

Now with the jog dial go options




Go SIM Card menu




To be able to see this you have to type this on the keypad on phone :

Type **'MEPD'** respectively **'MEPPD'** in case phone is 7100

Usually u should see active NET lock. Now in order to disable this lock type **'MEP2'** respectively **'MEPP2'** if phone is 7100 and will appear a dialog asking for code



Enter unlock code reader software gave you.



Phone unlocked. Now you can use any sim card you want !



How to hold shift key on Phone while entering code:



For more support please go bb dongle support forum or contact us for more information.

1-866-208-9805